

ST
suspensiontechniques

**PERFORMANCE
SUSPENSION
COMPONENTS**

EFFECTIVE: APRIL 1, 2003

APPLICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

PART NO. 90014





FULL LINE - COIL SPRING - ANTI-SWAY BAR & COMPLETE SETS

YEAR	APPLICATION	FOOTNOTES		COIL SPRING SET-F&R	INCH DROP	FRONT SWAY BAR	BAR DIAMETER	REAR SWAY BAR	BAR DIAMETER	F&R SWAY BAR SET
		FRONT	REAR							
ACURA (Also see "Speed Tech" competition springs)				(ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))						
96-97	2.2 CL, 4cyl.			60250	1.0"	_____	_____	_____	_____	_____
98-99	2.3 CL, 4cyl.			60250	1.0"	_____	_____	_____	_____	_____
95-99	2.5 TL, 5cyl.			60250	1.0"	_____	_____	_____	_____	_____
96-99	3.0 CL, 6cyl.			60257	1.5"	_____	_____	_____	_____	_____
95-97	3.2 TL, 6cyl.			60252	1.0"	_____	_____	_____	_____	_____
98-02	3.2 TL, 6cyl.		(F)	60252	1.0"	50137	7/8"	51137	3/4"	52137
86-89	Integra 2/4 dr.	(B)	(A) (E)	60265	1.0"	50140	5/8"	51115	3/4"	52145
90-93	Integra 2/4 dr.			60275	1.0"	50145	15/16"	51135	3/4"	52150
94-01	Integra 2/4dr. - all			60282	1.3"	50157	1"	51145	3/4"	52166
02-03	RSX			60286	1"	50156	1"	51156	13/16"	52156
87-90	Legend coupe 2dr.			60245	1.5"	_____	_____	_____	_____	_____
89-90	Legend 4dr.			60245	1.5"	_____	_____	_____	_____	_____
91-95	Legend coupe / sedan			60235	1.3"	_____	_____	_____	_____	_____
91-94	Vigor			60250	1.5"	_____	_____	_____	_____	_____
BMW				(ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))						
66-76	2002 - all		(F)	60015	0.5"	50000	7/8"	51000	3/4"	52000
77-9/78	320i			60020	1.0"	_____	_____	_____	_____	_____
10/78-83	320i		(F)	60020	1.0"	50005	1"	51005	3/4"	52005
84-91	318i 2/4dr.		(F)	60025	1.3"	50010	7/8"	51010	3/4"	52010
87-92	325 Cabriolet (E30)		(F)	60035	1.0"	50010	7/8"	51010	3/4"	52010
92-98	325i (E36 from 6/92)			60050	1.3"	_____	_____	_____	_____	_____
70-77	3.0 4dr. & Bavaria		(J) (F)	60060	1.0"	50015	1 1/8"	51015	7/8"	52015
79-81	528		(J) (F)	60060	1.0"	50015	1 1/8"	51015	7/8"	52015
82-88	528e / 533 / 535	(F)	(J) (F)	60065	1.0"	50020	7/8"	51020	5/8"	52020
72-78	530		(F)	_____	_____	50015	1 1/8"	51015	7/8"	52015
77-79	630 / 633		(F)	_____	_____	50015	1 1/8"	51015	7/8"	52015
80-81	630 / 633		(F)	60060	1.0"	50015	1 1/8"	51015	7/8"	52015
1982	630 / 633			60060	1.0"	_____	_____	_____	_____	_____
83-89	633 / 635		(G) (F)	60065	1.0"	50020	7/8"	51020	5/8"	52020
02-03	Mini Cooper							51025	13/16"	
BUICK				(ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))						
67-72	Skylark	(K)								
73-75	Apollo	(K)								
73-88	Regal	(K)								
82-91	Skylark (FWD)			60485	1.0"	_____	_____	_____	_____	_____
78-88	Grand Natl. V-6 / Regal V-8	(K) (L)		60490	1.0"	50245	1 3/8"	51235	1"	52245
92-95	Roadmaster sedan			60505	2.0"	_____	_____	_____	_____	_____
CHEVROLET (Also see "Speed Tech" competition springs)				(ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))						
87-93	Beretta 4cyl / 6cyl - all (exc. GTZ)			60485	1.0"	_____	_____	_____	_____	_____
67-81	Camaro	(K)								
82-92	Camaro - all V-8	(K) (L)	(D)	60110	1.0"	50075	1 3/8"	51055	1"	52075
82-92	Camaro V-6	(L)	(D)	60115	1.0"	50075	1 3/8"	51055	1"	52075
93-02	Camaro - V-8		(D)	60120	1.3"	50080	1 3/8"	51055	1"	52080
93-02	Camaro - V-6		(D)	60117	1.3"	50080	1 3/8"	51055	1"	52080
82-91	Cavalier / Corsica / Z-24			60485	1.0"	_____	_____	_____	_____	_____
95-03	Cavalier (exc. Convertible)	(Y)		60487	1.2"	_____	_____	_____	_____	_____
71-77	El Camino / Monte Carlo	(K)								
78-88	El Camino	(K)								
64-77	Chevelle / Malibu / Laguna	(K)								
78-88	Chevelle / Malibu / Monte Carlo SS /V-8	(K) (L)	(I)	60490	1.0"	50245	1 3/8"	51235	1"	52245
95-99	Monte Carlo			60510	1.2"	_____	_____	_____	_____	_____
68-79	Chevy II / Nova	(K)								
92-95	Caprice sedan			60505	2.0"	_____	_____	_____	_____	_____
94-96	Impala SS			60505	2.0"	_____	_____	_____	_____	_____
95-99	Lumina			60510	1.2"	_____	_____	_____	_____	_____
CHRYSLER				(ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))						
95-98	Cirrus 4 cyl. / 6 cyl.			60005	1.4"	_____	_____	_____	_____	_____
86-92	Lebaron / GTS - all			60010	1.0"	_____	_____	_____	_____	_____
00-03	P/T Cruiser		(AA)	60006	1.3"	50006	1 1/8"	51006	7/8"	52006
95-98	Sebring (exc. convertible)	(Y)		60342	1.3"	_____	_____	_____	_____	_____
DODGE				(ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))						
95-98	Avenger			60342	1.3"	_____	_____	_____	_____	_____
83-90	Conquest - all			60340	1.0"	50195	1"	51180	13/16"	52200
86-92	Daytona / Lancer / Shadow	(P)		60010	1.0"	_____	_____	_____	_____	_____
94-98	Neon	(S)		60000	1.2"	50002	15/16"	51002	13/16"	52002
99-03	Neon		(AA)	60002	1.0"	50004	15/16"	51004	3/4"	52004
95-99	Stratus 4 cvl. / 6 cvl.			60005	1.4"	_____	_____	_____	_____	_____



FULL LINE - COIL SPRING - ANTI-SWAY BAR & COMPLETE SETS

YEAR	APPLICATION	FOOTNOTES		COIL SPRING SET-F&R	INCH DROP	FRONT SWAY BAR	BAR DIAMETER	REAR SWAY BAR	BAR DIAMETER	F&R SWAY BAR SET
		FRONT	REAR							
EAGLE (ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))										
89-94	Talon (2WD)	(B)		60345	1.0"	50200	3/4"	51185	1"	52205
89-94	Talon (AWD)	(B)		60350	1.0"	50200	3/4"	51190	1"	52210
95-98	Talon (2WD)	(F)	(BB)	60355	1.3"	50205	3/4"	51192	3/4"	52212
95-98	Talon (AWD)	(F)	(BB)	60360	1.3"	50205	3/4"	51192	3/4"	52212
FORD (Also see "Speed Tech" competition springs) (ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))										
3/85-90	Escort 3dr. - all			60450	1.0"					
91-95	Escort 3dr. - all	(B)		60455	1.5"	50240	3/4"	51230	7/8"	52240
96-97	Escort - all			60455	1.5"					
98-03	Escort ZX2			60455	1.25"					
00-03	Focus (exc. Wagon)			60460	1.3"			51060	7/8"	
64-73	Mustang	(K)								
79-93	Mustang 4cyl. / 6cyl. (exc.SVO)		(I)	60085	1.0"	50050	1 3/8"	51040	15/16"	52045
79-93	Mustang V-8	(K)	(I)	60090	1.0"	50050	1 3/8"	51040	15/16"	52045
94-99	Mustang V-6 - all		(I) (CC)	60085	1.0"	50055	1 3/8"	51040	15/16"	52050
94-99	Mustang V-8		(I)	60090	1.0"	50055	1 3/8"	51040	15/16"	52050
00-03	Mustang V-6 - all		(I) (CC)	60085	1.0"	50055	1 3/8"	51040	15/16"	52050
00-03	Mustang V-8		(I)	60090	1.0"	50055	1 3/8"	51040	15/16"	52050
88-92	Probe - all			60305	1.0"					
93-97	Probe -all			60310	1.0"					
89-97	Thunderbird - except Super Coupe			60225	1.5"					
GEO (ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))										
93-97	Prizm			60370	1.3"					
90-94	Storm - all (exc. wagon)			60080	1.5"					
HONDA (Also see "Speed Tech" competition springs) (ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))										
86-89	Accord 2dr./ 4dr./ coupe	(N)		60240	1.0"	50130	15/16"	51110	5/8"	52130
90-97	Accord 2dr./ 4dr./ coupe -all			60250	1.0"	50135	1 1/16"	51120	13/16"	52135
95-97	Accord V-6			60257	1.5"	50135	1 1/16"	51120	13/16"	52135
98-02	Accord 4cyl.	(F)	(F)	60254	1.0"	50137	7/8"	51137	3/4"	52137
98-02	Accord 6cyl.	(F)	(F)	60252	1.0"	50137	7/8"	51137	3/4"	52137
2003	Accord Coupe			60256	1.5"			51137	3/4"	
2003	Accord 4cyl.			60258	1.5"			51137	3/4"	
2003	Accord 6cyl.			60259	1.5"			51137	3/4"	
84-87	Civic / 1500s	(A) (B)		60260	1.0"	50140	5/8"	51115	3/4"	52145
84-87	CRX - all	(A) (B)	(E)	60260	1.0"	50140	5/8"	51125	3/4"	52140
88-91	CRX / Civic - all	(H) (R)	(F)	60270	1.0"	50142	7/8"	51140	7/8"	52155
92-95	Civic (with original front bar)			60282	1.3"	50157	1"	51145	3/4"	52166
92-95	Civic (without original front bar)			60282	1.3"	50151	3/4"	51145	3/4"	52161
96-00	Civic (with original front bar)	(M)		60282	1.3"	50167	15/16"	51145	3/4"	52167
96-00	Civic (without original front bar)			60282	1.3"	50168	15/16"	51145	3/4"	52168
01-02	Civic (with original rear bar)			60284	1"	50154	1"	51154	13/16"	52154
01-02	Civic (without original rear bar)			60284	1"	50154	1"	51153	13/16"	52153
2003	Civic (all)			60284	1"	50154	1"	51154	13/16"	52154
93-97	Del Sol (without original front bar)			60282	1.3"	50151	3/4"	51145	3/4"	52161
93-97	Del Sol (with original front bar)			60282	1.3"	50157	1"	51145	3/4"	52166
83-87	Prelude			60315	1.0"					
88-91	Prelude - all			60320	1.0"					
92-96	Prelude - all (exc. 4wheel steer)	(Z)		60325	1.0"	50185	1"	51170	1"	52190
97-02	Prelude - (incl. SH)			60327	1.25"	50187	1"	51170	1"	52192
INFINITI (ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))										
95-98	I-30			60180	1.3"					
MAZDA (ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))										
92-96	MX-3			60335	1.3"					
90-98	Miata MX-5	(F)	(F)	60330	1.0"	50190	1"	51175	3/4"	52195
99-02	Miata	(F)	(F)	60332	1.5"	50197	1"	51177	9/16"	52197
88-92	MX-6			60305	1.0"					
93-97	MX-6			60310	1.0"					
91-94	Protege	(B)		60455	1.5"	50240	3/4"	51230	7/8"	52240
79-85	RX-7		(F)	60285	1.0"	50160	1 1/8"	51150	5/8"	52170
86-88	RX-7	(F)		60290	1.0"	50165	1 1/8"	51155	3/4"	52175
89-92	RX-7			60290	1.0"	50170	1 1/16"	51160	3/4"	52180
93-96	RX-7		(F)	60300	1.0"	50175	1 1/4"	51165	3/4"	52185
MERCURY (ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))										
79-89	Capri 4cyl./ 6cyl.			60085	1.0"	50050	1 3/8"	51040	15/16"	52045
79-86	Capri V-8	(K)		60090	1.0"	50050	1 3/8"	51040	15/16"	52045
67-73	Cougar	(K)								
89-97	Cougar - all			60225	1.5"					
91-95	Tracer - all	(B)		60455	1.5"	50240	3/4"	51230	7/8"	52240



FULL LINE - COIL SPRING - ANTI-SWAY BAR & COMPLETE SETS

YEAR	APPLICATION	FOOTNOTES		COIL SPRING SET-F&R	INCH DROP	FRONT SWAY BAR	BAR DIAMETER	REAR SWAY BAR	BAR DIAMETER	F&R SWAY BAR SET
		FRONT	REAR							
MITSUBISHI										
(ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))										
89-94	Eclipse (2WD)	(B)	(F)	60345	1.0"	50200	3/4"	51185	1"	52205
89-94	Eclipse (AWD)	(B)		60350	1.0"	50200	3/4"	51190	1"	52210
95-99	Eclipse (2WD)	(F)	(BB)	60355	1.2"	50205	3/4"	51192	3/4"	52212
95-99	Eclipse (AWD)	(F)	(BB)	60360	1.3"	50205	3/4"	51192	3/4"	52212
1999	Eclipse Spyder		(BB)			50205	3/4"	51192	3/4"	52212
00-03	Eclipse		(F)	60357	1.5"			51194	7/8"	
94-98	Galant (exc.4WD)			60364	1.0"					
83-91	Starion - all			60340	1.0"	50195	1"	51180	13/16"	52200
NISSAN / DATSUN										
(ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))										
93-97	Altima			60155	1.3"			51092	7/8"	
98-03	Altima			60155	1.3"			51097	7/8"	
86-88	Maxima			60170	1.5"					
89-94	Maxima			60175	1.5"	50115	1 1/4"	51095	3/4"	52115
95-98	Maxima			60180	1.3"					
87-90	Sentra 2dr./ 4dr.			60195	1.5"					
91-94	Sentra 2dr./ 4dr. -all		(U)	60195	1.5"	50125	1 3/16"	51105	3/4"	52125
95-98	Sentra - all			60205	1.5"	50122	1"	51127	3/4"	52127
91-94	NX-1600 / 2000		(U)	60200	1.5"	50125	1 3/16"	51105	3/4"	52125
95-98	200 SX			60205	1.5"	50122	1"	51127	3/4"	52127
89-94	240 SX			60125	1.3"	50085	1 1/16"	51065	13/16"	52085
95-98	240 SX			60130	1.3"	50090	1 1/8"	51065	13/16"	52090
70-73	240 Z			60135	1.0"	50095	1"	51075	3/4"	52095
8/74 on	260 Z			60145	1.0"	50100	1 1/8"	51080	7/8"	52100
75-78	280 Z	(T)		60145	1.0"	50100	1 1/8"	51080	7/8"	52100
79-83	280 ZX	(T)		60150	1.0"	50105	1 1/8"	51085	7/8"	52105
90-96	300 Z	(F)	(F)	60190	0.8"	50120	1 1/8"	51100	13/16"	52120
84-88	300 ZX (incl. Turbo)	(T)		60185	1.0"					
68-73	510 sedan (long strut)		(F)	60160	1.5"	50110	1"	51090	3/4"	52110
68-73	510 sedan (short strut)		(F)	60165	1.5"	50110	1"	51090	3/4"	52110
OLDSMOBILE										
(ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))										
68-70	Cutlass (exc. 442) (RWD)	(K)								
78-88	Cutlass V-8 (RWD) exc. wagon	(K) (L)		60490	1.0"	50245	1 3/8"	51235	1"	52245
82-91	Cutlass Calais (FWD) - all			60485	1.0"					
68-74	Omega	(K)								
PLYMOUTH										
(ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))										
90-94	Lazer (2WD)	(B)	(F)	60345	1.0"	50200	3/4"	51185	1"	52205
91-94	Lazer (AWD)	(B)		60350	1.0"	50200	3/4"	51190	1"	52210
87-92	Sundance			60010	1.0"					
95-98	Breeze			60005	1.4"					
PONTIAC										
(ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))										
84-87	Fiero - all			60210	1.5"					
67-81	Firebird	(K)								
82-92	Firebird (V-8/GTA)	(K) (L)	(D)	60110	1.0"	50075	1 3/8"	51055	1"	52075
82-92	Firebird (V-6 exc.GTA)	(L)	(D)	60115	1.0"	50075	1 3/8"	51055	1"	52075
93-02	Firebird - V-8		(D)	60120	1.3"	50080	1 3/8"	51055	1"	52080
93-02	Firebird - V-6		(D)	60117	1.3"	50080	1 3/8"	51055	1"	52080
68-79	Ventura II / Phoenix	(K)								
73-77	LeMans / Tempest	(K)								
78-88	Grand Prix V-8 (RWD)	(K) (L)		60490	1.0"	50245	1 3/8"	51235	1"	52245
85-91	Grand AM/Sunbird (FWD)	(Y)		60485	1.0"					
95-03	Sunfire (exc. Convertible)	(Y)		60487	1.2"					
2003	Vibe			60492	1.25"					
SATURN										
(ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))										
91-02	Saturn 2dr. / 4dr. / Wagon			60445	1.3"					
SUBARU										
(ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))										
02-03	WRX			60550	1.25"	50260	7/8"	51260	15/16"	52260
TOYOTA										
(ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))										
92-96	Camry 4cyl. (exc.wagon)			60372	1.0"					
93-94	Camry V-6			60375	1.3"					
86-89	Celica (2WD)			60380	1.3"					
90-93	Celica (2WD)		(F)	60385	1.5"			51200	7/8"	
94-99	Celica (2WD)		(F)	60385	1.5"	50210	15/16"	51200	7/8"	52217
00-03	Celica (2WD)		(F)	60387	1.2"			51212	7/8"	
87-91	Corolla 2dr. (FWD) exc. FX model			60365	1.5"					
93-97	Corolla			60370	1.3"					
2003	Matrix - all			60492	1.25"					
85-89	MR2 - all		(F)	60405	1.3"	50220	13/16"	51210	1/2"	52220



FULL LINE - COIL SPRING - ANTI-SWAY BAR & COMPLETE SETS

YEAR	APPLICATION	FOOTNOTES		COIL SPRING SET-F&R	INCH DROP	FRONT SWAY BAR	BAR DIAMETER	REAR SWAY BAR	BAR DIAMETER	F&R SWAY BAR SET
		FRONT	REAR							
TOYOTA (CONTINUED)										
(ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))										
90-95	MR2 - all		(F)	60410	1.3"	50225	15/16"	51215	7/8"	52225
91-94	Paseo / Tercel			60362	1.0"	_____		_____		_____
95-98	Tercel			60400	1.0"	_____		_____		_____
82-85	Supra			60390	1.3"	_____		_____		_____
7/86-92	Supra (incl. Turbo)		(F)	60395	1.3"	50215	1 1/8"	51205	15/16"	52215
VOLKSWAGEN (Also see "Speed Tech" competition springs)										
(ALPHA CODES ARE FOOTNOTES-PLEASE READ (PAGE 5))										
80-84	Jetta	(W)		60425	1.3"	50230	7/8"	51220	1"	52230
83-84	Rabbit GTI / Jetta GLI	(W)		60425	1.3"	50230	7/8"	51220	1"	52230
80-92	Rabbit Cabriolet	(W)		60425	1.3"	50230	7/8"	51220	1"	52230
82-89	Scirocco - all	(W)		60425	1.0"	50230	7/8"	51220	1"	52230
85-92	Golf / Jetta - II	(X)	(F)	60430	1.3"	50235	7/8"	51225	1"	52235
93-96	Golf / Jetta-A3 (4cyl.)	(X)	(F)	60430	1.0"	50235	7/8"	51225	1"	52235
90-95	Corrado 4cyl.	(X)	(F)	60435	1.0"	50235	7/8"	51225	1"	52235
92-95	Corrado 6cyl.		(F)	60435	1.0"	_____		51225	1"	_____

FOOTNOTES:

- (A) Sport Spring set includes 2 rear coils only. Lowering the front requires adjusting the torsion bars.
- (B) Suspension Techniques front anti-swaybar is used in conjunction with the original equipment front anti-swaybar (for simplified installation).
- (C) Anti-swaybars do not fit vehicles with front drum brakes or original equipment rear traction bars.
- (D) Order anti-swaybar adapter kit #55310 for vehicles NOT equipped with original equipment rear anti-swaybar.
- (E) Spring set contains 2 rear coils only.
- (F) Adjustable anti-swaybar.
- (G) For vehicles without hydro-adjust rear suspension. Hydro equipped vehicles (M5, M6, '89 635, etc.) use #60070 Spring Set. (see BMW M5 / M6 listing)
- (H) Order anti-swaybar adapter kit #55320 when installing anti-swaybar #52155 or #51140 on '88 model Civics.
- (I) Rear anti-swaybar will not fit with boxed control arms.
- (J) Must use stepped rear spring perch for rear coil spring.
- (K) See Muscle Car Application Guide.
- (L) Spring kit includes 2 urethane bump stops.
- (M) Order swaybar adapter kit #55360 for SI model.
- (N) Order swaybar adapter kit #55300 for non LXI models.
- (P) Coil Springs fit all except Shelby models.
- (R) Anti-swaybar only fits vehicles with original equipment front anti-swaybar.
- (S) Order anti-swaybar adapter kit #55335 for vehicles NOT equipped with original equipment rear anti-sway bar.
- (T) Coil Springs do not fit 2+2 model.
- (U) Order anti-swaybar adapter kit #55315 for vehicles NOT equipped with original rear anti-swaybar.
- (V) Equipped w/ Original Control Arms
- (W) Order anti-swaybar adapter kit #55325 for vehicles NOT equipped with original equipment front anti-swaybar.
- (X) Order anti-swaybar adapter kit #55330 for vehicles NOT equipped with original equipment front anti-swaybar.
- (Y) Coil Springs fit all except convertible models.
- (Z) Anti-swaybar does not fit vehicles with 4-wheel steering.
- (AA) Rear anti-sway bar # 51004 and # 51006 only fit vehicles equipped with original rear anti-sway bar.
- (BB) Order anti-swaybar adapter kit #55365 for vehicles NOT equipped with original equipment rear anti-swaybar.
- (CC) V-6 applications must use factory bolt part number w704939-s426 (Quantity 4) to mount sway bar end links.
- ETA:
Estimated Time Available
- NOTE:
For anti-swaybar adapter kits - see price guide.



SPEEDTECH MAXIMUM DROP COMPETITION SPRINGS

YEAR	APPLICATION	FOOTNOTES		DROP HEIGHT		PART NO.	RATE* FRONT	RATE* REAR
		FRONT	REAR	FRONT	REAR			
96-97	Acura 2.2 CL, 4cyl.	(L)	(P)	2.0"	2.0"	63010	250	180
98-99	Acura 2.3 CL, 4cyl.	(L)	(P)	2.0"	2.0"	63010	250	180
95-99	Acura 2.5 TL, 5cyl.	(L)	(P)	2.0"	2.0"	63010	250	180
96-99	Acura 3.0 CL, 6cyl.	(L)	(P)	2.3"	2.0"	63010	250	180
95-99	Acura 3.2 TL, 6cyl.	(L)	(P)	2.3"	2.0"	63012	270	150
90-93	Acura Integra - all	(P)	(P)	2.0"	1.8"	63020	425	215
91-94	Acura Vigor	(L)	(P)	2.0"	2.0"	63010	250	180
94-01	Acura Integra - all	(P)	(P)	2.3"	1.9"	63027	300	175
02-03	Acura RSX (Including Type S)	(P)	(P)	1.5"	1.75"	63026	225	430
93-02	Camaro / Firebird - V-6	(L)	(L)	1.2"	1.7"	63042	428	161
93-02	Camaro / Firebird - V-8	(L)	(L)	1.2"	1.7"	63045	428	161
79-99	Ford Mustang 5.0 (exc. convertible)	(L)	(P)	1.8"	2.0"	63000	850	280
86-89	Honda Accord - all	(P)	(P)	2.0"	1.9"	63005	365	230
90-93	Honda Accord - all	(L)	(P)	2.0"	1.8"	63010	250	180
94-97	Honda Accord - all	(L)	(P)	2.3"	2.0"	63010	250	180
98-02	Honda Accord 4cyl.	(L)	(P)	2.0"	2.0"	63014	270	150
98-02	Honda Accord 6cyl.	(L)	(P)	2.0"	2.0"	63012	270	150
2003	Honda Accord Coupe	(L)	(P)	2.75"	2.75"	63016		
2003	Honda Accord 4cyl.	(L)	(P)	2.75"	2.75"	63018		
2003	Honda Accord 6cyl.	(L)	(P)	2.75"	2.75"	63019		
88-91	Honda Civic / CRX - all	(P)	(P)	1.8"	1.8"	63015	315	185
93-97	Honda Del Sol	(P)	(P)	2.3"	2.0"	63027	300	175
92-95	Honda Civic - all	(P)	(P)	2.3"	2.0"	63027	300	175
96-00	Honda Civic - all	(P)	(P)	2.3"	2.0"	63027	300	175
01-03	Honda Civic (Including SI)	(P)	(P)	2.25"	2.0"	63024	180	500
92-96	Honda Prelude - all	(P)	(P)	2.0"	2.0"	63030	310	220
2003	Pontic Vibe	(P)	(L)	2.0"	2.0"	63092	200	220
2003	Toyota Matrix	(P)	(L)	2.0"	2.0"	63092	200	220
80-92	VW Cabriolet - all	(P)	(P)	1.3"	1.3"	63035	190	160
80-84	Jetta - all	(P)	(P)	1.5"	1.5"	63035	190	160
83-84	Rabbit GTI / Jetta GLI	(P)	(P)	1.5"	1.5"	63035	190	160
82-89	VW Scirocco - all	(P)	(P)	1.3"	1.3"	63035	190	160
85-92	VW Golf / Jetta - all	(P)	(P)	1.3"	1.3"	63040	200	150
93-96	VW Golf / Jetta-A3 / Cabriolet (4 cyl. - all)	(P)	(P)	1.5"	1.3"	63040	200	150

FOOTNOTES:

- (*) Spring rate expressed as lbs. per inch as measured at ride height.
- (L) Linear spring design.
- (P) Progressive / Variable/Dual Rate spring design.
- NOTE: The type of spring design selected is based on each particular vehicle application.
- NOTE: These competition-only products may lower the vehicle more or less than specified above due to variations in vehicle condition, options and accessories.
- NOTE: These competition-only products may not permit alignment of the vehicle to factory specifications.

SPEEDTECH COMPETITION ANTI-SWAY BARS - WITH LOWER TIE BRACE

ST now offers the best anti-sway bar and lower tie brace combination kit on the market. With an adjustable lower tie brace to tighten and strengthen the rear lower sub-frame, to the rear anti-sway bar with adjustable end links, these kits are guaranteed to improve handling. Each kit is designed for both street and/or race car applications. With features like as urethane bushings, anodized brackets, complete hardware, and easy to follow installation instructions, ST brings you the best performance and handling package for your import application.



YEAR	APPLICATION	FOOTNOTES	SWAY BAR	BAR DIA	
94-00	Acura Integra (exc. Type "R")		53148	7/8"	
97-98	Acura Integra Type "R"		53152	7/8"	
2000	Acura Integra Type "R"		53152	7/8"	
96-00	Honda Civic - all		53151	7/8"	
92-95	Honda Civic - all	(V)	53149	7/8"	

FOOTNOTES:

- (V) Equiped w/ Original Control Arms



MUSCLE CAR PERFORMANCE SPRINGS & ANTI-SWAYBAR SYSTEMS

YEAR	APPLICATION	FOOT NOTES	HEAVY DUTY SPRING STOCK HEIGHT		SPORT SPRING 1" LOWERED HEIGHT		ANTI SWAY BAR SET	FRONT SWAY BAR ONLY	SWAY BAR DIA.	REAR SWAY BAR ONLY	SWAY BAR DIA.
			FRONT	REAR	FRONT	REAR					
GENERAL MOTORS											
64-66	Chevelle, Malibu	(4) (5)	68510	68725	68512	68730	52070	50070	1 1/8"	51050	1 1/8"
64-66	El Camino	(4) (5)	68510	68725	68512	68730	52070	50070	1 1/8"	51050	1 1/8"
1967	El Camino	(4) (5)	68510	68735	68512	68740	52070	50070	1 1/8"	51050	1 1/8"
1967	Chevelle, Malibu, Skylark, (exc. Gran Sport)	(4) (5)	68510	68810	68512	68310	52070	50070	1 1/8"	51050	1 1/8"
68-72	Chevelle, Malibu, Skylark, (exc. Gran Sport)	(4) (5)	68535	68810	68115	68310	52065	50065	1 1/4"	51050	1 1/8"
68-70	Outlass (exc.442)	(4) (5)	68535	N/A	68115	N/A	52065	50065	1 1/4"	51050	1 1/8"
68-72	El Camino	(4) (5)	68535	68735	68115	68740	52065	50065	1 1/4"	51050	1 1/8"
71-72	Monte Carlo	(4) (5)	68535	68810	68115	68310	52065	50065	1 1/4"	51050	1 1/8"
73-75	Apollo	(0) (4) (5)	68545	68700	68120	68702	N/A	N/A	N/A	N/A	
73-77	Malibu, Monte Carlo, Regal, Laguna, Tempest, LeMans	(4) (5) (4) (5)	68545	68325	68120	68320	N/A	50065	1 1/4"	N/A	
75-79	Skylark	(0) (4) (5)	68545	68700	68120	68702	N/A	N/A	N/A	N/A	
73-77	El Camino	(4) (5)	68545	68735	68120	68740	N/A	50065	1 1/4"	N/A	
78-88	El Camino	(4) (5)	68532	68810	68105	68310	52245	50245	1 3/8"	51235	1"
78-88	Malibu, Monte Carlo, (exc. Diesel)	(4) (5)	68532	68810	68105	68310	52245	50245	1 3/8"	51235	1"
78-87	Regal (exc. Diesel)	(4) (5)	68532	68810	68105	68310	52245	50245	1 3/8"	51235	1"
1988	Regal (exc. Diesel)	(4) (5)	68532	N/A	68105	N/A	52245	50245	1 3/8"	51235	1"
68-74	Nova, Omega, Ventura	(0) (4) (5)	68505	68700	68507	68702	52055	50060	1 1/4"	51045	7/8"
83-87	Grand National, T-Type	(4) (5)	68105	68810	N/A	N/A	52245	50245	1 3/8"	51235	1"
75-79	Nova, Ventura, Phoenix	(0) (4) (5)	68530	68700	68532	68702	52060	50250	1 1/4"	51045	7/8"
67-69	Camaro, Firebird	(0) (1) (2) (5)	68505	68700	68507	68702	52055	50060	1 1/4"	51045	7/8"
70-81	Camaro, Firebird	(0) (5)	68530	68700	68532	68702	52060	50250	1 1/4"	51045	7/8"
82-92	Z-28 Camaro	(3) (5)	68514	N/A	N/A	N/A	52075	50075	1 3/8"	51055	1"
82-92	Camaro, Firebird (exc. Z-28)	(3) (5)	68532	68307	68105	68305	52075	50075	1 3/8"	51055	1"
FORD / MERCURY											
1964	Mustang	(5)	N/A	N/A	N/A	N/A	52030	50035	1 1/8"	51035	3/4"
65-66	Mustang	(0) (5)	68500	68900	68502	68902	52030	50035	1 1/8"	51035	3/4"
67-70	Mustang	(0) (5)	68540	68910	68542	68912	52035	50040	1 1/8"	51035	3/4"
71-73	Mustang	(0) (5)	68540	68910	68542	68912	52040	50045	1 1/8"	51035	3/4"
67-68	Cougar 2-Dr. (exc.GT)	(0) (5)	68500	68930	68502	68932	52035	50040	1 1/8"	51035	3/4"
67-68	Cougar (GT only)	(0) (5)	68500	68920	68502	68922	52035	50040	1 1/8"	51035	3/4"
1969	Cougar all	(0) (5)	68500	68940	68502	68942	52035	50040	1 1/8"	51035	3/4"
1970	Cougar all	(0) (5)	68540	68950	68542	68952	52035	50040	1 1/8"	51035	3/4"
71-73	Cougar all	(5)	68540	N/A	68542	N/A	52040	50045	1 1/8"	51035	3/4"
79-93	Mustang (& Capri thru '89)	(4) (5)	68520	68720	68100	68300	52045	50050	1 3/8"	51040	15/16"
FOOTNOTES:		(0)	Leaf springs sold individually. Order 2 of each part number for a complete set.								
		(1)	Rear spring does not fit vehicles with factory rear mono-leaf springs.								
		(2)	Anti-swaybars do not fit vehicles with front drum brakes or original equipment rear traction bars.								
		(3)	Order rear anti-sway bar adapter kit #55310 for vehicles NOT originally equipped with rear anti-sway bar.								
		(4)	Rear anti-swaybar will not fit with boxed control arms.								
		(5)	All applications are for V-8 small block rear wheel drive only - except for Grand National which is a V-6.								

PIVOT BUSHINGS AND BRACKETS						END LINK ASSEMBLIES	
(kit includes 2 bushings and 2 brackets)						(kit includes 2 complete links)	
Eliminate anti-sway bar deflection and reduce body roll (lean). Bushings feature exclusive grooved bore for quiet, durable performance.						Improve anti-sway bar response and vehicle control. Includes heavy duty urethane grommets and high grade plated hardware.	
ANTI-SWAYBAR MATERIAL DIAMETER			MOUNTING BOLT SPACING FROM CENTER TO CENTER ON BRACKET			LENGTH FROM MOUNT TO MOUNT INCHES	PART NUMBER
INCH	DEC	METRIC	2.0"-2.5"	2.5"-3.0"	3.0"-4.0"		
7/16	0.438	11mm	55600	55650	N/A	2"	55105
7/16	0.438	11mm	55600	55650	N/A	2.5"	55110
1/2	0.500	13mm	55605	55655	N/A	3"	55115
9/16	0.562	14mm	55610	55660	N/A	3.5"	55120
5/8	0.625	16mm	55615	55665	N/A	4"	55125
11/16	0.688	17mm	55620	55670	N/A	5"	55135
3/4	0.750	19mm	55625	55675	N/A	5.5"	55140
13/16	0.812	21mm	55630	55680	N/A	6"	55145
7/8	0.875	22mm	55635	55685	55710		
15/16	0.938	24mm	55640	55690	55715		
1	1.000	25mm	55645	55695	55720		
1-1/16	1.062	27mm	N/A	55700	55725		
1-1/8	1.125	28mm	N/A	55705	55730		
1-3/16	1.188	30mm	N/A	N/A	55735		
1-1/4	1.250	32mm	N/A	N/A	55740		
1-5/16	1.312	34mm	N/A	N/A	55745		
1-3/8	1.375	35mm	N/A	N/A	55750		
						END-LINK GROMMETS URETHANE	
						8 piece set	55100
						URETHANE BUMP STOPS	
						3/4" (2 pcs)	55000
						1-1/2" (2pcs)	55005



MUSCLE CAR URETHANE BUSHINGS KITS

FRONT CONTROL ARMS					REAR CONTROL ARMS		
YEAR	APPLICATION	FRONT UPPER	FRONT LOWER	FRONT COMPLETE KIT	REAR COMPLETE KIT	REAR LEAF KIT ONLY	OTHER
GENERAL MOTORS							
64	Chevelle, Malibu, El Camino, Skylark, GS, 442, Cutlass, LeMans, Tempest, GTO (exc.'74 GTO)	54500	54750	54070	54090 (1)		
65		54500	54750	54070	54085		
66		54500	54750	54070	54085		
67		54500	54700	54025 (2)	54085		
68-72		54500	54745 (3)	54065 (3)	54085		
			54700	54025			
73		54505	54710	54035	54085		
74		54520	54715 (4)	54040 (4)	54085		
			54710 (5)	54060			
75-77		54520	54710	54045	54085		
78-88		Chevelle, Malibu, El Camino, Monte Carlo, Regal, Grand National, Cutlass, Grand Prix	54550	54755 (6)	54075 (6)	54085	
68-74	Chevy II, Nova, Apollo, Omega, Ventura II, (incl.'74 GTO)	54500	54700	54025		54005 54000 (7)	
75-79	Nova, Apollo, Omega, Ventura II, Phoenix	54520	54710	54045		54005	
67-69	Camaro, Firebird	54500	54700	54025		54005 54000 (7)	
70-72		54505	54700	54030		54005	
73-74		54505	54710 (5)	54035 (5)		54005	
75-79		54520	54715	54040	54045	54005	
			54710	54050			
80-81		54525	54710	54050		54005	
82-92			54730 (8)		54095		54130 (rear panhard)
63-74	Corvette	54500	54735	54055	54080 (9)	54010	54110 (rear strut rod)
75-82		54500	54735	54055	54080 (9)	54010	54115 (rear strut rod)
FORD/MERCURY							
64-66	Mustang		54760 (8)			54015 (14) 54020 (15)	54120 (front strut rod)
67-73	Mustang, Cougar		54765 (9,10) 54775 (9,19)			54015	54125 (front strut rod)
79-82	Mustang (and Capri thru'86)		54770 (9,11) 54780 (9,12)		54100 (9) 54105 (9,13)		54135 (rack & pinion)
83-93	Mustang		54770 (9)		54100 (9) 54105 (9,13)		54140 (20) (rack & pinion) 54145 (strut tower)
FOOTNOTES:							
1	Uppers must use existing shells.				10	1.437" OD lower bushings.	
2	1.65" OD rear lower bushing.				11	Except heavy duty suspension.	
3	Oval rear lower control arm bushings, must use existing ovalshells.				12	Heavy duty suspension only.	
4	With 1.375" OD front lower bushings.				13	With oval rear lower bushings.	
5	With 1.625" OD front lower bushings.				14	Fits 1/2" shackle bolts.	
6	Front lower bushings must use existing shells.				15	Fits 9/16" shackle bolts.	
7	For monoleaf (single leaf) rear springs only.				16	Does not fit vehicles with factory rear traction bars.	
8	Lowers only, must use existing outer shells.				19	1.562" OD lower bushings.	
9	Must use existing outer shells.				20	For vehicles built before 10/1/84, use P/N 54135.	

Our continual goal is to design the best possible way to lower a vehicle and improve the performance. In the process we have developed a very useful product offering called - Pro-Align™. Our Pro-Align kits provide everything needed to align your vehicle with the accuracy of a race car. In fact many pro-race teams use both our Pro-Align™ and Toe-Adjust™ to achieve the best alignment obtainable. Each kit includes everything required to properly adjust your alignment.

New product features include: The new adjustable Pro-Align™ BallJoint that provides up to 3 degrees of camber and 1 degree of caster. Our new Pro-Align™ Cam-Bolts that allow you to make full camber adjustments with the simple turn of a bolt. And ToeAdjust, our rear toe adjusters that provide a wide range adjustment.



ST PRO-ALIGN™ KIT APPLICATIONS

YEAR	DISCRIPTION	ALL FOOTNOTES	CASTER	CAMBER	FRONT CAMBER/CASTER KIT NO.	FRONT KIT DEGREES	REAR CAMBER KIT NO.	REAR KIT DEGREES
ACURA								
90-00	INTEGRA	(A) (D) (E)	X	X	57432	+/- 1.5°	57440	1.2° max
91-95	LEGEND	(A) (D)	X	X	57430	+/- 1.5°	57440	1.2° max
02-03	RSX (Including Type S)	(B)		X	57420		57424	
91-94	VIGOR	(A) (F)	X	X	57430	+/- 1.5°		1.2° max
97-99	2.2 CL	(A) (D)	X	X	57430	+/- 1.5°	57440	1.2° max
97-99	2.3 CL	(A) (D)	X	X	57430	+/- 1.5°	57440	1.2° max
97-99	3.0 CL	(A) (D)	X	X	57430	+/- 1.5°	57440	1.2° max
95-98	2.5 TL	(A) (D)	X	X	57430	+/- 1.5°	57440	1.2° max
95-99	3.2 TL	(A) (D)	X	X	57432	+/- 1.5°	57440	1.2° max
96-99	3.5 RL	(A)	X	X	57432	+/- 1.5°		1.2° max
BUICK								
97-98	CENTURY	(B)		X	57422		57422	
97-98	REGAL	(B)		X	57422		57422	
80-95	SKYLARK	(B)		X	57422			
CHEVROLET								
1996	BERETTA/CORSICA	(B)		X	57422			
95-98	CAVALIER	(B)		X	57422			
97-98	MALIBU	(C)		X	57420		57420	
86-89	SPECTRUM	(C)		X	57420			
86-89	SPRINT	(C) (G)		X	57420			
97-98	VENTURE VAN	(B)		X	57422			
CHRYSLER								
95-99	SEBRING	(A) (D)	X	X	57434	+/- 1.5°	57442	1.2° max
DAIHATSU								
88-92	CHARADE	(B)		X	57420			
DODGE								
95-00	AVENGER 2WD/ AWD	(A) (D)	X	X	57434	+/- 1.5°	57442	1.2° max
79-94	COLT	(C) (H)		X	57420			
84-91	COLT VISTA 4X2	(C) (G)		X	57420			
85-91	COLT VISTA 4X4	(C) (F)		X	57420			
95-99	NEON	(B)		X	57422			
EAGLE								
89-96	SUMMIT	(B) (F)		X	57422			
92-96	SUMMIT WAGON	(B) (G)		X	57422			
95-98	TALON 2WD/ AWD	(A) (D)	X	X	57434	+/- 1.5°	57442	1.2° max
89-94	TALON 2WD/ AWD	(C) (F)		X	57420			
89-91	VISTA WGN. 4X2/ 4X4	(C) (G)		X	57420			
FIAT								
71-79	128 CPE., HATCH, WGN	(C) (G)		X	57420			
74-81	131/BRAVA	(C) (G)		X	57420			
79-82	STRADA	(C) (F)		X	57420			
74-82	X1/9	(C)		X	57420		57420	
FORD								
94-97	ASPIRE	(C)		X	57420			
91-98	ESCORT/ZX2	(C)		X	57420		57420	
88-93	FESTIVA	(C)		X	57420			
78-80	FIESTA	(C) (G)		X	57420			
89-97	PROBE	(C)		X	57420		57420	
GEO								
1989	SPECTRUM	(C)		X	57420			
90-93	STORM	(C)		X	57420			
89-98	TRACKER 4X2/4X4	(C) (G)		X	57420			
89-97	METRO	(C) (G)		X	57420			
HONDA								
90-97	ACCORD	(A) (D)	X	X	57430	+/- 1.5°	57440	1.2° max
98-00	ACCORD	(A) (G)	X	X	57432	+/- 1.5°		
01-03	Civic (Including SI)	(B)		X	57420		57424	
92-99	CIVIC/CRX/CR-V	(A) (D) (E)	X	X	57432	+/- 1.5°	57440	1.2° max
93-97	DEL SOL	(A) (D) (E)	X	X	57432	+/- 1.5°	57440	1.2° max
92-96	PRELUDE	(A) (I)	X	X	57430	+/- 1.5°		
97-99	PRELUDE SH	(A) (G)	X	X	57430	+/- 1.5°		
97-00	PRELUDE	(A) (F)	X	X	57432	+/- 1.5°		1.2° max
HYUNDAI								
95-98	ACCENT	(C)		X	57420		57420	
92-98	ELANTRA	(C) (G)		X	57420			
86-94	EXCEL	(C) (G)		X	57420			
91-96	SCOUPE	(C) (G)		X	57420			
89-98	SONATA	(C) (J)		X	57420			
97-98	TIBURON	(C)		X	57420		57420	
INFINITI								
91-98	G20	(C)			NON ADJ.		57420	
96-98	I30	(B) (G)		X	57422			

ST PRO-ALIGN™ KIT APPLICATIONS

YEAR	DISCRIPTION	ALL FOOTNOTES	CASTER	CAMBER	FRONT CAMBER/CASTER KIT NO.	FRONT KIT DEGREES	REAR CAMBER KIT NO.	REAR KIT DEGREES
ISUZU								
85-90	I-MARK	(C)		X	57420			
90-93	IMPULSE	(C)		X	57420		57420	
90-93	STYLUS	(C)		X	57420		57420	
KIA								
94-97	SEPHIA	(C) (G)		X	57420			
MAZDA								
86-98	323/PROTÉGÉ ALL	(C)		X	57420		57420	
79-98	626	(C)		X	57420		57420	
88-89	626 4WS	(C)		X	57420		57420	
81-85	GLC	(C)		X	57420		57420	
89-98	MPV 4X2/4X4	(C)		X	57420		57420	
92-96	MX-3	(C)		X	57420		57420	
88-98	MX-6 2WS/4WS	(C)		X	57420		57420	
79-95	RX-7	(C) (K)		X	57420			
MERCURY								
91-94	CAPRI	(C)		X	57420		57420	
97-98	TRACER	(C)			FAC. ADJ		57420	
87-96	TRACER	(C)		X	57420		57420	
93-98	VILLAGER	(C)		X	57420			
MITSUBISHI								
83-88	CORDIA	(C) (G)		X	57420			
92-98	DIAMANTE	(C) (L)		X	57420			
93-96	DIAMANTE WGN.	(C) (G)		X	57420			
2000	ECLIPSE	(G)						
95-99	ECLIPSE 2WD/4WD	(A) (G)	X	X	57434	+/- 1.5°		1.2° max
89-94	ECLIPSE 2WD/4WD	(C) (M)		X	57420			
94-98	GALANT	(A) (F)	X	X	57434	+/- 1.5°		1.2° max
85-93	GALANT 2WD/4WD	(C) (G)		X	57420			
85-98	MIRAGE	(C) (F)		X	57420			
88-93	PRECIS	(C) (G)		X	57420			
85-90	SIGMA	(C) (G)		X	57420			
83-89	TREDIA	(C) (G)		X	57420			
NISSAN								
95-98	200SX	(C) (G)		X	57420			
89-98	240SX	(C) (F)		X	57420			
92-98	ALTIMA	(C) (G)		X	57420			
95-98	MAXIMA	(B) (G)		X	57422			
85-94	MAXIMA-ALL	(C) (G)		X	57420			
91-94	NX COUPE	(C)		X	57420		57420	
87-90	PULSAR	(C)		X	57420		57420	
83-86	PULSAR	(C) (G)		X	57420			
95-98	SENTRA	(C) (G)		X	57420			
87-94	SENTRA- ALL	(C)		X	57420		57420	
82-86	SENTRA	(C) (G)		X	57420			
82-92	STANZA	(C) (G)		X	57420			
86-90	STANZA 4WD WAGON	(C)		X	57420		57424	
OLDSMOBILE								
96-98	ACHIEVA	(B)		X	57422			
97-98	CUTLAS	(B) (G)		X	57422			
1998	INTRIGUE	(B)		X	57422		57422	
97-98	SILHOUETTE	(B)		X	57422			
PLYMOUTH								
79-82	CHAMP	(C) (G)		X	57420			
92-94	COLT	(C) (F)		X	57420			
93-94	COLT VISTA	(C) (G)		X	57420			
89-94	LASER 2WD/4WD	(C) (N)		X	57420			
PONTIAC								
96-98	GRAND AM	(B)		X	57422			
97-98	GRAND PRIX	(B)		X	57422		57422	
85-88	SUNBURST	(C)		X	57420			
95-98	SUNFIRE	(B)		X	57422			
97-98	TRANS PORT	(B)		X	57422			
PORSHCE								
77-88	924	(C)(F)		X	57420			
82-92	944	(C)(F)		X	57420			
RENAULT								
83-87	ALLIANCE	(C)(G)		X	57420			
84-87	ENCORE	(C)(G)		X	57420			
SATURN								
91-98	ALL MODELS	(B)		X	57422		57422	
SUBARU								
93-98	IMPREZA- ALL	(B)					57422	
89-98	LEGACY- ALL	(B)					57422	
92-97	SVX	(B)					57422	
SUZUKI								
95-98	ESTEEM	(C)(G)		X	57420			
89-98	SWIFT	(C)(G)		X	57420			
TOYOTA								
95-98	AVALON						57420	
83-86	CAMRY	(C)		X	57420		57420	
88-97	COROLLA FWD						57420	
84-87	COROLLA FWD	(C)		X	57420		57420	
87-88	FX-16	(C)		X	57420		57420	
85-89	MR-2	(C)		X	57420		57420	
92-98	PASEO	(C)(G)		X	57420			
83-86	TERCEL	(C)		X	57420		57420	
VOLKSWAGEN								
95-98	CABRIOLE	(C)		X	57420			
89-94	CORRADO	(C)		X	57420			
87-94	FOX	(C)		X	57420			
85-98	GOLF/GTI	(C)		X	57420			
80-98	JETTA	(C)		X	57420			

ST PRO-ALIGN™ KIT APPLICATIONS

YEAR	DISCRIPTION	ALL FOOTNOTES	CASTER	CAMBER	FRONT CAMBER/CASTER KIT NO.	FRONT KIT DEGREES	REAR CAMBER KIT NO.	REAR KIT DEGREES
VOLKSWAGEN (Continued)								
90-98	PASSAT	(C)		X	57420			
82-88	QUANTUM	(C)		X	57420			
75-84	RABBIT	(C)		X	57420			
80-83	SCIROCCO	(C)		X	57420			
VOLVO								
93-98	850 FWD/AWD	(B)(G)		X	57422			
1998	C70, S70, V70	(C)(G)		X	57420			
1998	S90, V90	(C)(G)		X	57420			
FOOTNOTES:		(A) Adjustable upper balljoint sold separately						
		(B) 14mm 12.9 high strength bolt - each kit will give up to .75 degree						
		(C) 12mm 12.9 high strength bolt - each kit will give up to .75 degree						
		(D) Shims 4ea. 0.2-0.4°						
		(E) See our Rear Toe Adjuster applications						
		(F) Rear factory adjustable						
		(G) Rear non-adjustable						
		(H) 93-94 models, factory adjustable.						
		(I) 92-94 AWS models, factory adjustable.						
		(J) 95-98 models, factory adjustable.						
		(K) 93-95 models, factory adjustable.						
		(L) 92-96 models, factory adjustable.						
		(M) AWD factory adjustable						
		(N) 2WD factory adjustable						



ST TOE-ADJUST™ RACING - A MUST FOR THE HONDA PERFORMANCE ENTHUSIAST!

ST rear toe adjusters are part of our new ProAlign™ program. Toe Adjusters are designed to allow a wide range of toe adjustment on the most popular Honda and Acura applications. A light weight competition component, that corrects the toe out condition associated with lowering a vehicle for competition.



RACING TOE ADJUSTER APPLICATIONS

YEAR	APPLICATION	PART NO.	CORRECTION
90-00	INTEGRA	57400	+/- .75"
88-99	CIVIC/CRX/CR-V	57400	+/- .75"
93-97	DEL SOL	57400	+/- .75"



SUSPENSION TECHNIQUES, INC.
2822 EAST CALIFORNIA AVENUE
FRESNO, CALIFORNIA 93721 USA
TOLLFREE: 800.595.7016
PHONE: 559.266.9173
TELEFAX: 559.266.4348

©2003 SUSPENSION TECHNIQUES, INC. ALL RIGHTS RESERVED